

Ford Focus MK2

Rear Lower Chassis Panel



**Tools Required: 18MM socket 19MM
Spanner**



Job time approx. 5-15 Mins

Step 1.

Lift your car either on a car lift or using a jack and jack stands.

Step 2.

Using a 19MM spanner hold the front side of the bolt still while you remove the 18MM nut on the back side. (If the bolt moves your rear tracking will be out)



Step 3.

Put the brace onto the two bolt treads then put the nut from step 2 back on top of the brace making sure to hold the head of the bolt with the 19MM spanner while tightening the nut.

